



Replace the toner cartridge

To access and replace the toner cartridge, open the cartridge access door, remove the old toner cartridge, and then install a new one.

1. Open the cartridge access door.




2. Remove the toner cartridge.



3. Recycle the old cartridge.
4. Remove the new cartridge from the packaging.

CAUTION:

Hold the cartridge at each end to prevent damage. Do not touch the protective cover or roller surface.



5. Grasp both sides of the cartridge, and then gently rock to distribute the toner evenly inside the cartridge.

